www.arctic.ac





support.arctic.ac/S111M

Dear Customer,


Thank you for choosing the ARCTIC S111 M.

This compact system is the perfect upgrade from your stock computer speakers. An extra large driver-magnet allows us to get the maximum out of these small boxes. I hope you enjoy the S111 M and we at ARCTIC look forward to further enriching your life with our products. If you would like to share how you use ARCTIC's products please do so at https://www.facebook.com/ARCTIC.en

ARCTIC is a fully carbon neutral company and your support helps us to compensate every kilogram of  ${\rm CO_2}$  we produce. Thank You.


Sincerely,

Magnus Huber ARCTIC CEO



# **Function Diagram**

- ① Volume Control
- 2 3.5mm Audio Output
- 3 Micro-USB Charging Port




# Using your S111 M

# Connect your S111 M to a Music Source

The S111 M speaker system can be connected with smartphones, music players and computers.

- Switch ON your S111 M by turning the volume wheel clockwise.
- Insert the 3.5mm audio cable into your device's headphone output.
- 3. Play music




#### **LED Power Indicator**

| LLD Fower indicator |                    |  |
|---------------------|--------------------|--|
| OFF                 | No light           |  |
| ON /                | Blue light On      |  |
| Battery above 50%   | Red light Off      |  |
| ON /                | Blue light On      |  |
| Battery 25 - 49%    | Red light On       |  |
| ON /                | Blue light On      |  |
| Battery below 24%   | Red light Blinking |  |

#### ON / OFF

Turn off: Turn the volume wheel anti-clockwise until the wheel clicks

Turn on: Turn the volume wheel clockwise



## **Volume Control**


**Volume up:** The more you turn the volume wheel clockwise, the greater the volume

Volume down: Turn the volume wheel anti-clockwise



# **Charging Your S111 M**

Connect the S111 M to computer or USB charger.



### **LED Power Indicator**

| Charging     | Red light  |
|--------------|------------|
| Full Charged | Blue light |

| Specifications     |  |
|--------------------|--|
| Frequency Response | 50Hz – 25KHz   |
| Impedance          | 4Ω   |
| Output Power       | 4W (2W x 2) RMS  |
| Audio Input        | 3.5mm Stereo Jack on cable   |
| Battery Type       | Rechargeable Lithium-ion Polymer 2000mAh   |
| Battery Life       | Charging : 4-5 hours<br>Playing : 12 hours   |
| Power Input        | DC 5V, 1A, Micro USB   |
| Dimensions         | 70 (L) x 70 (W) x 70 (H) mm<br>(per speaker)<br>161 (L) x 106 (W) x 90 (H) mm<br>(carrying case) |
| Weight             | 451 g  |

### Cautions

- Keep S111 M dry, moisture may damage electronic components.
- Exposure to high temperature will shorten the life and damage electronic components.
- Opening / altering the S111 M voids all product warranty.
- Rough handling may damage inside electronic components













### © 2014 ARCTIC Switzerland AG. All Rights Reserved.

No part of this manual including the products described in it, may be reproduced, transmitted, stored in a retireal system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purpose, without the express written permission of ARCTIC Switzerland AG. In no event shall ARCTIC is directors or employees be iable for any indirect damages, incidental or consequential damages arising from any defect or error in this manual or product.